


DESPIECE CZ SHADOW



Picture from the [CZ 75 SP-01 SHADOW Instruction Manual](#).

- 1 Frame *
- 2 Slide Stop
- 3 Slide Stop Spring
- 4 Slide Stop Spring Pin
- 5 Trigger
- 6 Trigger Pin
- 7 Trigger Bar
- 8 Trigger Spring
- 9 Pin (3x)
- 10 Ejector
- 11 Sear
- 12 Sear Spring
- 13 Sear Pin
- 14 -
- 15 -
- 16 Hammer
- 17 Disconnecter
- 18 Hammer Pin
- 19 Hammer Pin Retaining Peg
- 20 Main Spring Strut
- 21 Main Spring
- 22 Main Spring Plug
- 23 Main Spring Plug Pin
- 24 Magazine Guide
- 25 Magazine Guide Pin
- 26 Grip Panel - Left *
- 27 Grip Panel - Right *
- 28 Grip Panel Screw (2x)
- 29 Safety - Left *
- 30 Safety Detent Plunger - Left
- 31 Safety Detent Plunger Spring (2x)
- 32 Magazine Catch
- 33 Magazine Catch Spring
- 34 Trigger Bar Spring
- 35 Magazine Catch Spring Screw
- 36 Magazine Body *
- 37 Magazine Base
- 38 Magazine Base Lock
- 39 Magazine Spring *
- 40 Follower
- 41 Recoil Spring *
- 42 Recoil Spring Guide *
- 43 Barrel *
- 44 Slide *
- 45 Front Sight
- 46 Front Sight Pin
- 47 Loaded Chamber Indicator *
- 48 Loaded Chamber Indicator Spring *
- 49 Loaded Chamber Indicator Nut *
- 50 Extractor *
- 51 Extractor Pin
- 52 Extractor Spring
- 53 Rear Sight
- 54 Firing Pin *
- 55 Firing Pin Spring
- 56 Firing Pin Stop *
- 57 Securing screw (2x)
- 58 Safety - Right
- 59 Safety Detent Plunger - Right
- 60 Shaped Washer (2x)

CZ 75 SP-01 Shadow Detailed Field Strip